



# Testing in minimum time with ivy "seen enough & stop"

August 9, 2016

Allart Ian Vogelesang

[ian.vogelesang@hds.com](mailto:ian.vogelesang@hds.com)


 **Hitachi Data Systems**

- Valid results are *repeatable*
  - If you run the test again, within specified +/- experimental error, you will get the same result again.
  - Valid, repeatable, results are for steady-state conditions
- If the workload / subsystem are not steady-state, you can't make a valid measurement.
  - After imposing a workload on the subsystem
    1. we need to wait for the behaviour to settle down into a steady state, waiting for initial transient conditions to settle down, then
    2. depending on how much "noise" there is in what is being measured, measure for long enough to obtain a valid measurement to a specified plus/minus accuracy.


# An ivy test is a sequence of "subintervals"

- The default is `subinterval_seconds = 5`
- At end of subinterval, workload thread measurement data sent to ivymaster.
- ivymaster decides to continue the test for another subinterval, or to stop.
- For most workloads, subsystem response is very stable, so you can make an accurate measurement quite quickly.
- For some workloads where behaviour is more dynamic, either due to initial transient behaviour or else instability, we need to test longer to get an accurate measurement

measure=IOPS, accuracy\_plus\_minus=5%



measure=IOPS, accuracy\_plus\_minus=5%



- The ivy "measure" feature extends the test until enough measurements have been made to be statistically confident that the average of the by-subinterval values is within a specified accuracy\_plus\_minus variation from what the long term average would be continuing to test indefinitely.

- `accuracy_plus_minus = "5%"`
  - Default is "5%".
  
- `confidence = "95%"`
  - How confident you need to be that your measurement falls within the specified plus or minus range around the long term average that you would get measuring forever.
  - Default is "95%"
  - Ivy has a menu of 11 specific pre-loaded confidence values that you pick from.
    - 50%, 60%, 70%, 80%, 90%, 95%, 98%, 99%, 99.5%, 99.8%, and 99.9%

- It is both convenient and effective to use the standard statistical formulas using the `accuracy_plus_minus` and confidence parameters
  - [http://en.wikipedia.org/wiki/Student%27s\\_t-distribution](http://en.wikipedia.org/wiki/Student%27s_t-distribution) (sorry, for the math literate)
- Limitation – the standard formulas don't exactly apply to ivy
  - The formulas are for samples drawn at random from a large population.
  - The behaviour / measurement for one subinterval is related to those for preceding / succeeding subintervals, thus "gaming the system".
- Rule of thumb to correct for this
  - Specify an `accuracy_plus_minus` parameter for twice the required accuracy, and you'll be safe.
    - Say `accuracy_plus_minus = 5%` to get repeatability within 10%.


# measure parameter "shorthand" presets

- `measure = IOPS`  
`measure = MB_per_second`  
`measure = service_time_seconds`  
`measure = response_time_seconds`
- These are "shorthand"
  - See "ivy programmer's reference" for more detail




- Instead of running for a fixed 6 minutes for each step of the several hundred combinations / permutations of a standard scalability test sequence, when a variable step run time using `measure` was used
  - Overall test run time decreased by 60%
    - The vast majority of the time workloads settled down quickly and were then stable.
  - Quality was improved
    - In some rare cases, there were test steps that needed to run for 20 minutes to get an accurate measurement.
- The use of the `measure` feature in ivy substantially reduces test time, while at the same time improving quality.

# measure automatically rejects initial transients



# How it works - example of "have not seen enough"



# warmup\_seconds, measure\_seconds, subinterval\_seconds

- warmup\_seconds – default = 5
- measure\_seconds – default = 60
- Without `measure`, the warmup and measurement periods are fixed.
- When `measure` is used, these `warmup_seconds` and `measurement_seconds` values represent minimum periods during automatic detection of a valid measurement.
- `subinterval_seconds` default is 5
  - Don't make this shorter, but if you are running really long test steps, you could use longer subintervals to reduce the volume of csv output.

- The `measure` feature is convenient and effective to run tests for the minimum necessary number of subintervals
  - In one example, overall test time was reduced by 60% while measurement quality was improved.
- Standard small sample set math is effective with a 2x fudge factor.
  - Say `accuracy_plus_minus=5%` and the rule of thumb is you will safely get a measurement repeatable to within 10%.



# Questions and Discussion



**HITACHI**  
Inspire the Next

# Thank You

 **Hitachi Data Systems**